



Typical Installation



Room 160
IP 196.168.0.1



Room 161
IP 196.168.0.2



Room 200
IP 196.168.0.10



Room XXX
IP 196.168.0.X